



This hack guard rest between the front of the hack and the backboard. The long back piece rest along the backboard and extends out at least 6 inches past the hack.



The long back piece should be at least 3 feet long for stability. But I recommend 4 feet. The front square is attached to it and extends at least 6 inches past the front of the hack and lies flat on the ice. It should only be a few inches wider than the width of your hacks. This unit can be made out of 2 X 4 lumber.